

# Mini Quick Fist Installation Instructions

1. Use either #10 screw or bolt and washer (Do Not Over tighten); or use 4 sheet metal screws and washers through the holes on the four corners of the pad.
2. The MINI QUICK FIST can be mounted with the strap facing in any direction.
3. To clamp: Put the tool or implement into the jaws and push the strap to its desired tightness.
4. The MINI QUICK FIST clamps are great as pipe stand-offs, but do not use on pipes whose temperature consistently exceeds 180 degrees F (or 82 degrees C).



**TWO CLAMPS PER PACKAGE**